

Innolux VC-PHI

8156

Photoinitiator solution for adjusting the reactivity of Innolux VC-Base Color 2783079891

PRODUCT DESCRIPTION

Product numbers


8156079890

General

Concentrated photoinitiator solution for adjusting the reactivity of Innolux VC-Base Color 2783079891.
Helpful for adjusting reactivity to an existing UV system with low UV lamp output.

Application area

Additive for Innolux base and top coats for most application methods.



PROCESSING

Processing instructions



- Please shake / stir the product before use.
- The temperature of the product and object, and the room temperature must be at least + 15 °C.
- Innolux VC-PHI (8156) must be incorporated carefully into the hardened varnish by stirring.
- Slight thinning effect in the coating material after addition.
- Paints/varnishes that have been mixed can be used as explained in the relevant technical data sheet.
- Any change in the processing sequence, environmental conditions, non-observance of instructions or the use of products not listed may have an unfavourable effect on the result.
- Please observe our **ARL 210 - Working guidelines for Innolux coating systems**.

Quantity to be added



Quantity to be added: 0.5% - 2% relative to the quantity of paint or varnish.

The amount added varies depending on the area of application and UV system. Please contact your sales representative.

In individual cases, the addition of Innolux VC-PHI (8156) can also cause a deterioration in reactivity, especially in the case of overdosing!

Cleaning the working equipment

With Waschverdünner (8501) immediately after use.



8501

ORDERING INFORMATION**Size of trading unit**

250 ml

FURTHER DETAILS**Durability / storage**

Min. 6 month(s) in the original sealed containers.

Make sure the product is protected against moisture, direct sunlight, frost and high temperatures (above 30 °C).

Safety information

The product is only suitable for industrial use.

During work, wear fastened-up working clothes, protective gloves made of butyl rubber and safety goggles with side protection! If the product comes into contact with your eyes, rinse immediately with water and consult a doctor! Remove dirty, soaked clothing immediately! If the product comes into contact with your skin, wash off immediately with plenty of soap and water!

Further information on the subject of safety during transport, storage and handling as well as disposal can be found in the relevant safety data sheet. The current version can be accessed on the Internet at www.adler-lacke.com.
